



**ROCK RIVER
LABORATORY, INC.**
AGRICULTURAL ANALYSIS

710 Commerce Dr.
P.O. Box 169
Watertown, WI 53094-0169

Voice: 920-261-0446
Email: office@rockriverlab.com
Website: www.rockriverlab.com

Mixer Accuracy Evaluation Example Report

Mixer Manufacturer Type: None Listed

Mixer ID: Protein Mix

Mixer Size: None Listed

Batch Quantity:

Mixing Time:

Producer: Rock River Laboratory Mill Colby - QA Account

Description: Mixer Accuracy 1 South

Sample ID	Protein	Ca	P	Salt	Lab No
1	14.196	5.399	.203	4.378	BBBBB
2	14.563	5.692	.203	4.955	CCCCC
3	16.501	5.405	.213	4.181	DDDDD
4	15.595	5.101	.205	3.973	AAAAA
Average	15.214	5.399	.206	4.372	
Standard Deviation	.903	.209	.004	.366	
Coefficient of Variation	5.936	3.875	1.928	8.370	
Expected Levels	15.15	5.42	.204	4.300	